

## AROMATHERAPY – FOR ADULT USE ONLY:

If using this humidifier in an adult's room or a home without children, adding two to three drops of your favorite essential oils into the water tank allows the humidifier to fill the room with a pleasant aroma. **NOTE:** If using essential oils, you may need to clean the humidifier more frequently as these oils can leave a residue.

### Cleaning and Maintenance

**IMPORTANT:** Before any cleaning, always switch the appliance off and unplug it.

1. Remove the basket from the water tank by rotating counter-clockwise.
  2. Remove the basket ring from the basket.
  3. Apart from the electrical controls, any part of the humidifier may be cleaned with a soft damp cloth and then wiped with a dry cloth.
- NOTE:** Check the nebulizer for mineral deposits. These can happen over time and are especially common in areas with hard water. These deposits will influence the humidification process and gradually decrease performance.
4. To clean mineral deposits from the nebulizer, dampen a soft cloth with vinegar and wipe the nebulizer gently until the mineral deposits disappear. You may also use a very soft brush, like a toothbrush to gently remove the deposits.
  5. Use a dry clean cloth to rub it down.

**IMPORTANT:** Do NOT use hard or abrasive objects to clean the nebulizer. NEVER use chemical products to clean the nebulizer.

6. After cleaning, place the basket ring back inside of the basket. Reinstall the basket by rotating clockwise.

### Notes about Humidity

1. It is best to keep the humidity level at about 30-50 percent of relative humidity.
2. The level of humidity needed will vary from room to room and with changing room conditions.
3. In cold weather, especially in unventilated areas, windows and even some walls may fog or develop frost from excessive indoor humidity. If this occurs, reduce the mist setting to avoid damage from condensed water dripping on windows, walls, or furniture.
4. To prevent excessive humidity, especially in small rooms, leave the room door open and use a lower mist setting.

This device complies with Part 18 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**FCC WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC NOTE:** This equipment has been tested and found to comply with the limits for Consumer ISM equipment, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or locate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-1(B)/NMB-1(B)

If you have a warranty question or any other customer care questions, please contact our Customer Care team by calling 800-704-8697 or by e-mailing [cs@tomy.com](mailto:cs@tomy.com). You can also visit our warranty page at: <https://us.tomy.com/warranty>

DISTRIBUTED BY TOMY


© 2020 TOMY, TOMY INTERNATIONAL, 45 SHAWMUT ROAD, CANTON, MA 02021 U.S.A.  
ALL RIGHTS RESERVED. ACTUAL PRODUCT COLOR MAY VARY FROM WHAT IS SHOWN. MADE IN CHINA.  
THE FIRST YEARS is the U.S. registered trademark of TOMY  
Y7818 201208

the **first** years<sup>®</sup>  
TOMY



American  
Red Cross







ALWAYS READY



# Remote Control Ultrasonic Humidifier Instruction Manual

READ ALL INSTRUCTIONS  
BEFORE USING.  
KEEP THESE INSTRUCTIONS  
FOR FUTURE REFERENCE.  
FOR HOUSEHOLD USE ONLY.

1. Nebulizer
2. Water Level Gauge with Floater
3. Air Tower
4. Water Tank
5. Tank Lid
6. Mist Vent
7. Control Panel
8. Basket
9. Basket Ring
10. LED Nightlight on/off switch (back of unit)
11. Remote Control



Capacity: 2.2 L (0.58 gal)  
Main material: PP  
Rated voltage: 120V AC, 60HZ  
Output: about 130 ml/h (4.4 oz/h)

### CAUTION

- Adult assembly is required. Keep small parts away from children.

## **WARNING:**

- ALWAYS turn off appliance and unplug to clean.
- DO NOT immerse appliance in water.
- DO NOT use scouring pads, solvents or abrasive cleaners to clean.

Y7818

# WARNING:

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to person, including the following:

- Use appliance only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by the manufacturer may cause hazards.
- To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet. **DO NOT** plug in the cord with wet hands.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, **NEVER** put the cord under rugs or near heat registers.
- **DO NOT** operate any appliance with a damaged cord or plug, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Return appliance to nearest authorized service facility for examination, electrical or mechanical adjustment, or repair.
- **DO NOT** attempt to repair or adjust any electrical or mechanical functions on this unit. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- No serviceable parts inside.
- **DO NOT** use outdoors.
- **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
- The use of accessory attachments is not recommended by the appliance manufacturer as they may cause injuries.
- **DO NOT** use appliance for other than intended use.
- Humidifier should be unplugged when not in use.
- **DO NOT** place humidifier near heat sources such as stoves, radiators, and heaters. **DO** locate your humidifier on an inside wall near an electrical outlet. The humidifier should be at least 4 inches (10 cm) away from the wall for best results. **DO NOT** allow the mist outlets to directly face the wall. Moisture could cause damage, particularly to wallpaper.
- **NEVER** place humidifier in an area where it is accessible to children. **NEVER** use humidifier in a closed room, particularly where a child may be sleeping, resting, or laying (a closed room may result in excessive humidity).
- **DO NOT** attempt to refill humidifier without first unplugging the unit from its electrical outlet. Failure to heed this warning may cause personal injury. Be sure to unplug the unit by pulling on the plug and not the cord. **NEVER** tilt, move, or attempt to empty unit while it is operating. Shut off and unplug before moving the unit.
- **DO NOT** block air inlet or outlet while unit is running.
- Always place humidifier on a firm, flat, level surface. A waterproof mat or pad is recommended for use under the humidifier. **NEVER** place it on a rug or carpet, or on a finished floor that may be damaged by exposure to water or moisture. To prevent damage to surfaces, **DO NOT** place humidifier under overhanging surfaces.
- **DO NOT** use humidifier in an area where humidity level is in excess of 50%. Use a hygrometer, available at your local retailer, to measure the humidity. Turn humidifier off if excessive humidity occurs.
- **DO NOT** pour water in any openings other than the water tank.
- **NEVER** place base under water flow or immerse in liquids.
- **NEVER** operate unit without water in the tank.
- **NEVER** touch exposed metal diaphragm in base after use. Metal will be HOT.
- This humidifier requires daily and weekly maintenance to operate appropriately. Refer to Cleaning and Maintenance procedures. **Use only cleaners recommended by the manufacturer.**
- **NEVER** drop or insert any object into any openings.

**IMPORTANT:** This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

# WARNING:

- SWALLOWING THE BATTERY, IF IT IS DISLODGED, COULD BE FATAL.
- **DO NOT** allow your child to bite, hit, or remove, the battery cover.

- Keep batteries away from children. Parents are urged to exercise care in the storage, use, and disposal of all batteries.
- **DO NOT** dispose of battery in fire; it may explode.
- **DO NOT** attempt to recharge battery.

## USING YOUR HUMIDIFIER

### Set Up

**NOTE:** Humidifier should always be on a solid, level, and moisture-resistant surface.

1. Ensure that the humidifier is unplugged.
2. Remove the lid from the top of the tank.
3. Fill the tank with water. **DO NOT** fill above the MAX fill line.
4. Place the lid back on to the top of the water tank.
5. Plug in the humidifier and press on/off icon to turn it on.

**NOTE:** If the low water alert appears and the humidifier still has enough water, check to confirm that the floater has not become stuck below the water line. Please reference #2 on the diagram on page 1.

For optimal performance, we recommend using distilled water.

### Mist Control

Pressing the Mist icon allows you to control the level of mist.

0 – Stop Mist (Use this setting when you only want to use the Light Show mode)

1 – Low Mist

2 – Medium Mist

3 – High Mist

The chosen mist level is shown directly above the on/off icon. The humidifier features 360 degree mist control. Rotate the cover so that the mist vent points in your chosen direction. **NOTE:** **DO NOT** aim mist directly at your child, the wall, or nearby furniture.

### Sleep Mode

Pressing the Sleep icon will dim the control display and turn off the light show (if it is running), but the humidifier will continue to operate normally. Pressing any icon will undim the control display lights and turn the light show back on.

### Timer Mode

Time mode allows you to choose a set amount of time that the humidifier will run in hourly increments, from 1 to 8 hours. Press the Time icon to cycle through the different times. Your chosen time will display above the on/off icon with the word "Timer" to the right of it. While the timer is operating, the display will alternate between the chosen time and the chosen mist level. The time will also count down as each hour passes to let you know how much time is left; from 8 to 7 etc. To keep the humidifier running constantly, cycle through the time options until the timer display disappears.

### Remote Control

The remote control can be used to turn the humidifier On and Off, choose Mist Levels, Activate Sleep Mode, and Choose Timer Mode settings. Simply point the remote at humidifier, press the appropriate button on the remote and follow the instructions in the sections above. The remote uses one CR2025 battery. To change the battery, reference the diagram on the back of the remote control.

### Temperature Display

The display panel will show the temperature of the area surrounding the humidifier. The actual room temperature may vary by +/- 6°F depending on other environmental factors. (Windows and doorways, etc.)

### Light Show Mode

Use the red switch at the rear of the humidifier to turn the multicolored LED nightlights on and off. **NOTE:** If you turn the humidifier off using the display panel or remote control, the lights will also turn off.

### Auto Shut Off

This humidifier has a safety system that switches it off before the water runs out. When the water is almost empty, a red alert symbol will show on the control panel. This safety feature protects the nebulizer from being damaged due to lack of water and lets you know it's time to add more water.

### IMPORTANT:

- Water level should **NEVER** be higher than the top of the max fill line.
- When first using, we do **NOT** recommend setting the mist output to the maximum level. Too much mist could cause a pool of water to form near the humidifier.
- It is best to start with lower mist settings until you confirm what works best for your home's unique humidity levels.
- If the humidifier is not producing mist, confirm that it is turned on and that the mist setting has not been set to 0.